



Remove wraps from the NED Yo so there is just 1 left for tricks 4-6 (see below).



Always keep three wraps on the Boomerang™.

4

Spinner

SLEEPER TRICK

5

Walk the Dog


SLEEPER TRICK

6


Rock the Baby

SLEEPER TRICK


1. Start this trick just like the Gravity Gripper, but gently stop your hand as the yo-yo reaches the end of the string. If done correctly, the yo-yo will spin or "sleep."




1. Start by throwing a good Spinner. As the yo-yo swings forward, lightly let it touch down on the floor.




2. Turn your hand over (palm down) and give the string a tug. If there is still enough spin, the yo-yo will climb back up the string right into your hand.



2. Let the yo-yo "walk" in front of you.
3. Before it runs out of spin give the string a small tug so the yo-yo will return to your hand.




1. After throwing a good Spinner, grab the string a little above the middle with your free hand.



2. Bend the string down with your yo-yo hand, and pinch the string about 5 inches (13 cm) above your yo-yo.



3. Now swing the triangle down between you and your yo-yo and bring it into place, forming the cradle.



NED TIP The harder you throw your yo-yo down the longer it will spin AND the looser the string must be.

NED TIP A hard floor surface - wood, gym or kitchen - works best for "walking your dog!"

NED TIP Try the trick a few times before adding the spin.


YO-YO WON'T STAY & SPIN?

Your string is too "tight." Look down at your yo-yo, and turn it counterclockwise, like the hands of a clock moving backward. Now try it...
If your Boomerang won't spin, use a harder overhand throw.


YO-YO WON'T COME UP?

Your string is too "loose." Look down at your yo-yo and turn it clockwise. Or, simply let the yo hang down and it will naturally tighten. Now try it...

HOW TO WIND THE STRING on the EXCEerator/Cosmic Spin



1. Make the first wrap over one finger.




2. Continue to wrap string around the axle, to the side of your finger, 2-3 times.


3. Remove finger and gently continue wrapping until wound.

4. The finger loop will disappear when you throw the yo-yo down!

HOW TO ADD or REMOVE WRAPS





1. Pinch the string about 3 inches (7 cm) above your yo.



2. As you look down at your yo-yo, spin it counterclockwise until the strands of the string split apart.

3. TO REMOVE WRAPS: Take off one wrap at a time until there is only 1 wrap left around the axle.

TO ADD WRAPS: Add one wrap at a time until there are 3 wraps (NED Yo) or 5 wraps (Cosmic/EXCEerator) around the axle.



4. Let go of the pinched string, and the yo-yo will spin, returning the string to its natural position.

